



Pilot's Operating Instruction Manual for the Curtiss P-40 Series D&E "Warhawk"

Revised 4-10-43

c 2004 www.zenoswarbirdvideos.com

INDEX OF REVISION PAGES ISSUED

<u>Page</u>	<u>Latest Revised Date</u>
I	4-10-43
15	4-10-43
15A	4-10-43
15B	4-10-43
15C	4-10-43
15D	4-10-43
15E	4-10-43
15F	4-10-43
15G	4-10-43

NOTE: A heavy black vertical line, to the left of the text on revised pages, indicates the extent of the revision. This line is omitted where more than 50 percent of the page is revised.

**THIS PUBLICATION MAY BE USED BY PERSONNEL RENDERING
SERVICE TO THE UNITED STATES OR ITS ALLIES**



Paragraph 5.d. of Army Regulation 380-5 relative to the handling of "restricted" printed matter is quoted below.

"d. Dissemination of restricted matter. The information contained in restricted documents and the essential characteristics of restricted material may be given to *any person known to be in the service of the United States and to persons of undoubted loyalty and discretion who are cooperating in Government work*, but will not be communicated to the public or to the press except by authorized military public relations agencies."

This permits the issue of "restricted" publications to civilian contract and other accredited schools engaged in training personnel for Government work, to civilian concerns contracting for overhaul and repair of aircraft or aircraft accessories, and to similar commercial organizations.

TABLE OF CONTENTS

<u>Section</u>	<u>Page</u>	<u>Section</u>	<u>Page</u>
I Description	1	V Operation of Communications Equipment	16
1. Airplane	1	1. Radio Set SCR-283 (P-40D Airplane)	16
2. Power Plant	2	2. Radio Set SCR-274-N (P-40E Airplane)	17
3. Propeller	2	3. Radio Set SCR-522A (P-40E Airplane)	17
4. Operational Equipment	2	4. Pip Squeak (Contactor) Operation - RC-96 (P-40E Airplane)	18
II Pilot Operating Instructions	11	VI Armament Equipment	19
1. Before Entering the Pilot's Compartment	11	1. Bombing Equipment	19
2. On Entering the Pilot's Compartment	11	2. Gunnery Equipment, P-40D Airplane	19
3. Starting Engine	12	3. Gunnery Equipment, P-40E Airplane	19
4. Engine Warm-up	12		
5. Emergency Take-off	12	<u>Appendix</u>	
6. Engine and Accessories Ground Test	12	Cold Weather Operation	20
7. Taxiing Instructions	12	1. Engine Oil Dilution System	
8. Take-off	12	2. Portable Ground Heater (Type D-1)	
9. Engine Failure During Take-off	13	3. Cold Weather Starting of Engines	
10. Climb	13	4. Batteries	
11. Flight Operation	13	5. Frost or Ice Removal	
12. General Flying Characteristics	13	6. Mooring	
13. Engine Failure During Flight	13	7. Communications Equipment	
14. Stalls	13		
15. Spins	13	Emergency Operating Instructions	21
16. Acrobatics	13	1. Emergency Take-off	
17. Diving	14	2. Engine Failure During Take-off	
18. Emergency Exit	14	3. Engine Failure During Flight	
19. Approach, Landing and Cross-Wind Landing	14	4. Emergency Take-off if Landing is not Completed	
20. Stopping of Engine	14	5. Emergency Exit	
21. Before Leaving the Pilot's Compartment	14	6. Emergency Operation of Landing Gear	
22. Maneuvers Prohibited	14	7. Emergency Operation of Wing Flaps	
III Flight Operation Data	15	8. Emergency Bomb Release	
1. Determining Gross Weight	15	9. Belly Tank Release	
2. Flight Planning	15		
IV Operation of Oxygen Equipment	15G	Glossary	22
1. Operation	15G		
2. Oxygen Duration	15G		

SECTION I

DESCRIPTION

1. Airplane.

a. General. - The P-40D and P-40E Fighter Airplanes are manufactured by the Curtiss-Wright Corporation at Buffalo, New York under contracts W535 ac-12414 and -15802. They are low wing, land monoplanes, each powered by one model V-1710-39 engine. The engine drives a three-bladed electrically-operated propeller. Hydraulically-operated landing gear, tail wheel, wing flaps, and brakes are provided. The approximate over-all dimensions are as follows:

Length	31 ft 8-3/4 in.
Height, taxiing position	10 ft 8 in.
Span	37 ft 3-1/2 in.

b. Access to Airplane. - Access to the airplane is gained through the canopy over the pilot's cockpit. The canopy may be opened by pressing a flush type release button located at the extreme top rear frame of the windshield proper. If no button is provided, the canopy is held shut by a friction grip, and it may be opened by placing one hand on each side of the canopy and giving it a sudden backward push.

c. Fuel, Oil, and Coolant.

(1) Fuel: Specification No. AN-VV-F-781,
Amend. 5
Grade: 100 Octane

(2) Oil: Specification No. AN-VV-O-446
Viscosity: Summer - 1120
Winter - 1100

(3) Coolant: Ethylene glycol.

d. Pilot Protection. - Front and rear armor protection sufficient to withstand enemy fire by direct right angle hit is provided for the pilot. Enemy fire originating within the areas graphically illustrated in figure 1 will not reach the pilot.

e. Mooring Provisions. - Tie-down rings are located in the undersurface of each wing near the wing tip. They are held in a retracted position in the wing by springs, and can be pulled down through slots by small tabs which protrude through the bottom surface of the wing. A towing ring on the inboard end of each landing wheel axle can also be used for tie-down purposes.

f. Fuel System. - See figure 4.

g. Oil System. - See figure 5. Oil dilution is provided.

h. Cooling System. - See figure 6.

i. Hydraulic System. - See figure 7.




Figure 1 - Angles of Armor Protection




Figure 2 - Fuselage Contents Arrangement Diagram




Figure 3 - Cockpit Canopy Release Diagram

2. Power Plant.

The V-1710-39 engine is a 12-cylinder vertical "V" type aircraft engine, glycol cooled, is equipped with integral reduction gears through which the propeller is driven, and is provided with a Bendix-Stromberg model PD-12K-2 carburetor.

3. Propeller.

The Curtiss constant speed electrically-operated propeller may be controlled automatically or manually. When controlled automatically, a predetermined engine speed is held constant by means of a governor set by the propeller control on the throttle quadrant.

When controlled manually, the blade angle is varied by operation of the switch (figure 10) which is independent of the governor.

4. Operational Equipment.

a. Airplane Controls.

(1) Cockpit Seat. - The cockpit seat may be adjusted for height by lifting the lock release handle on the right side of the seat, and then raising or lowering the seat as desired. To lock the seat in position, release the locking handle and "juggle" the seat slightly in a vertical direction until its spring-loaded locking device definitely snaps into position.




Figure 4 - Fuel System Diagram




Figure 5 - Oil System Diagram




Figure 6 - Cooling System Diagram




Figure 7 - Hydraulic System Diagram

(2) Aileron and Elevator. - Conventional control stick, equipped with a thumb-operated hydraulic system "OFF-ON" button on the top of the grip, and a squeeze type machine gun trigger lever on the front side of the grip.

(3) Rudder Control. - Conventional pedals and toe-operated brakes. Each rudder pedal may be adjusted to desirable length by first pushing inboard on the spring-loaded adjustment lock which permits the pedal to float free on its hinge. After moving pedal to desired location, release lock and juggle pedal slightly to allow locking pin to snap into position. ALWAYS ADJUST BOTH PEDALS TO THE SAME LENGTH.

(4) Elevator Trim Tab Control. - The trim tab is actuated by a round control knob (figure 8) on the left side of the cockpit. The knob has calibration marks around its outer circumference. Rotating the knob clockwise (forward) puts the airplane nose down.

(5) Rudder Trim Tab Control. - The rudder tab is actuated by a round control knob (figure 8) on the left side of the cockpit. Rotating it to the left (counter-clockwise) turns the nose of the airplane to the left.

(6) Aileron Trim Tab Control. - The aileron trim tab is electrically controlled. When the switch (figure 10) is raised, the left wing raises, and when the switch is pushed down, the left wing lowers. The switch returns to a neutral "OFF" position when released, allowing trim tab to remain as adjusted.

(7) Landing Gear and Tail Wheel. - Hydraulically actuated with provisions for automatic power or hand operation.

(a) Gear Down. - The landing gear may be lowered (WHEN THE IAS IS 175 MPH OR LESS) by pulling the safety latch bolt on the landing gear lever (figure 8) forward, and lowering the handle to its "DOWN" position. Press the hydraulic control switch button on top of the control stick until a few seconds after the indicator (figure 10) shows the gear to be down and locked in place. As a final check, operate the hand pump (figure 9) and if a high pressure is required to move it, the gear is down. If the landing gear warning horn fails to sound when the throttle lever (figure 8) is closed, the landing gear locks are definitely in place. RETURN THE CONTROL LEVER (FIGURE 8) TO "NEUTRAL." The safety latch bolt prevents the accidental raising of the handle beyond the neutral position.

NOTE: The gun charging valve handles must be in the "OUT" position when operating the landing gear.

(b) Gear Up. - The gear may be raised at any speed. Pull the safety latch bolt on the landing gear control lever (figure 8) forward, and raise the handle to its "UP" position. Press the hydraulic switch button on the top of the control stick until the indicator (figure 10) on the instrument panel shows the gear completely up. RETURN CONTROL HANDLE (FIGURE 8) TO "NEUTRAL" AFTER GEAR IS RETRACTED.




Figure 8 - Cockpit - Left Side






Figure 9 - Cockpit - Right Side

Figure 10 - Cockpit - Front



Detail "A"



(c) Emergency Operation. - If the hydraulic switch button on the top of the control stick fails to operate the landing gear, manually operate the auxiliary hand pump. (See figure 9.) If this fails to operate the gear, manually operate the emergency hand pump. (See figure 9.) When the emergency system is used to lower the landing gear, a "tail high" landing must be made, because the emergency system does not operate the tail wheel.

(8) Wing Flaps Operation. - Hydraulically actuated with provisions for automatic power or emergency hand operation.

(a) Flaps Down. - Move flap control lever (figure 8) to "DOWN" position. Press button on top of control stick until a second or two after indicator shows flaps are down. If a high pressure is required to move the auxiliary hand pump, the wing flaps are fully extended. RETURN FLAP CONTROL HANDLE TO "NEUTRAL" AFTER EXTENSION.

CAUTION: DO NOT LOWER FLAPS WHEN AIR SPEED IS ABOVE 140 MPH.

(b) Flaps Up. - Move flap control lever to "UP" position. Press button on top of control stick until a few seconds after indicator on instrument panel shows flaps are retracted. RETURN FLAP CONTROL LEVER TO "NEUTRAL" AFTER RETRACTION.

NOTE: The flaps may be placed in any intermediate position by releasing the button on the control stick when the flap position indicator shows the desired deflection.

(9) Landing Gear Warning Horn. - The horn may be tested by first turning the ignition switch (figure 10) to "BAT" and then turning the landing gear warning horn switch "ON." Sounding of the horn indicates that the horn and its circuits are in good working order. Turn switches "OFF."

(10) Warning Horn Disconnect Switch. - Pull out the cam on the throttle rod to disconnect the switch temporarily. Automatic engagement of the switch results the next time the throttle is opened to its stop, placing the warning horn back in operation.

(11) Heating and Ventilation Control. - Pull the control (figure 9) for heat and push for cold. The control may be set for any intermediate position. Closing the radiator shutters increases the temperature of the air coming into the cockpit.

(12) Fuel Tank Gages. - Gages are direct visual reading gages. It is not necessary to operate any switch to place them in operation.

(13) Fuel Selector Valve. - Conventional. (See figure 8.)

CAUTION: Do not turn pointer through "BELLY" when the belly tank is not installed.

(14) Radiator Shutter Control. - Move the control (figure 9) up to close and down to open the shutters. Set as the coolant and outside temperatures require. This control is equipped with an index finger release lock which must be operated before the shutter control can be moved. The coolant temperature warning lamp (figure 10) can be tested by operating the small test switch. (See figure 10.)

CAUTION: Do not extend radiator shutters at IAS in excess of 175 mph.

(15) Parking Brake. - The parking brake lever (figure 10) will lock the wheels if pulled when the toe brakes are depressed. The parking brake will release automatically by pressing on the toe brakes.

(16) Lights.

(a) Cockpit Lights.

1. The ignition switch (figure 10) must be turned to "BAT" before any lights will function by operation of their individual switches. Turn on cockpit lights by placing switch (figure 10) in the "ON" position. Adjustment of the knurled ring on the end of the flexible fluorescent lamp will control its light.

2. A cockpit spotlight (figure 9) is located on each side of the cockpit, and both are controlled by a switch (figure 10) on the central control panel.

3. The brilliancy of the compass light and the gun sight may be regulated by turning the two rheostat controls. (See figure 10.)

(b) Landing Light. - After the switch (figure 10) has been turned on, the light will not glow until after the landing light mechanism has extended the lamp to its operating position. Do not operate the landing light at speeds in excess of 175 mph. The switch has three positions, up and down for "ON" and neutral for "OFF." When the switch is placed in the upper "ON" position, the landing light swings down and out of the left wing. The light automatically illuminates after passing the center line of the pivot. When the switch is placed in the lower "ON" position, the landing light retracts up into the wing and is automatically turned off. The entire circuit is open when the toggle is in the neutral "OFF" position.

CAUTION: Do not test operate the light for more than 5 seconds. Do not operate the light for more than 3 minutes.

(17) Windshield Defroster Control. - The glycol spray pump must be operated by hand to force the liquid onto the windshield.

(18) Coolant and Fuel Pressure Test Switch. - The switch (figure 10) is a double-throw momentary contact toggle switch with two "ON" positions and a neutral "OFF" position. The coolant test "ON" position is the upper "ON" position, and the fuel pressure test "ON" position is the lower.

(19) Pilot's Shoulder Strap Adjustment. - The locking pin handle may be placed in the locked or unlocked position by pressing the button on its top and moving it fore or aft. When the handle is in the aft position, the locking pin is in the released position and the only restraining force on the shoulder straps is the bungee spring. The straps may be locked by having the bungee in its retracted position and inserting the locking pin by placing the handle in the forward position.

(20) Cockpit Enclosure.

(a) General. - Fore and aft movement of the enclosure is controlled by a crank (figure 9) located on the right side of the cockpit. The canopy can be locked in the closed position from the outside by inserting a padlock through the locking lug on the lower left side of the canopy frame.

(b) Emergency Exit on Ground. - In case of a turn-over on the ground, the kick-out panel on the left side of the canopy may be opened by pulling handle (figure 3) inward and aft which disengages the panel frame from the canopy frame and allows the panel to swing open. The canopy can also be opened from the outside by pulling the release handle outward and forward.

(c) Emergency Exit During Flight. - Pull down on release tab located on the upper forward beam of the canopy.

WARNING Before every flight be sure that the canopy release mechanism is lockwired shut. If lock wires are not installed, the canopy may be ripped off by slipstream, causing serious damage to the airplane.

(21) Parking Harness. - The control surfaces are locked by rigging the parking harness around the control stick. The short cables on the harness fasten into the eyes on the rudder pedal frames and the long cables fasten into the eyes on the pilot's seat frame. The parking harness is stowed in the fuselage baggage compartment.

b. Power Plant Controls.

(1) Throttle Control. - Conventional.

(2) Mixture Control. - On the left side of pilot on throttle quadrant and has four positions: "IDLE CUT-OFF," "AUTO LEAN," "AUTO-RICH," and "FULL RICH."

(a) To increase engine power during flight, set the mixture control in "AUTO-RICH," adjust propeller to desired rpm, adjust the throttle to obtain the desired manifold pressure and then readjust the mixture control if necessary.

(b) To decrease engine power, adjust the throttle to obtain desired manifold pressure and adjust the propeller control to obtain desired rpm. Readjust mixture control if necessary.

(3) Oil Dilution. - When a cold-weather start is expected, the oil should be diluted before the engine is stopped. Operate the engine at about 800 rpm and hold the oil dilution switch (figure 10) "ON" for about 4 minutes.

(4) Propeller Control. - Whenever the airplane is being operated, the safety switch (figure 10) should be "ON." When the switch opens due to overload, it may be reset by placing it in the "OFF" position and then returning it to the "ON" position. Propeller pitch may be changed independently of the rest of the propeller control system by holding the three-way toggle switch (figure 10) in either the "INC. RPM" or "DEC. RPM" position until the desired rpm is obtained. The automatic constant speed control may be used by placing the switch in the "AUTO" position and setting the propeller governor control lever (figure 8) to the required rpm.

NOTE. The markings on the propeller control are approximate. The desired rpm should be obtained accurately by reading the tachometer.

(5) Primer Control. - The primer (figure 9) must be turned counterclockwise to the "ON" position and pumped to prime the engine.

(6) Carburetor Heat Control. - This control (figure 10) operates a hinged vane in the carburetor air intake duct elbow and permits either warm air from the engine compartment or cold air from outside to enter the carburetor.

NOTE: The engine should be operated on "FULL COLD" at all times unless engine behavior leads the pilot to believe that carburetor icing conditions are being experienced and in that case, the control should be moved to "FULL HOT." If this does not clear up the trouble, the control should again be returned to the "FULL COLD" position.



SECTION II

PILOT OPERATING INSTRUCTIONS

1. Before Entering the Pilot's Compartment.

Check weight and balance.

2. On Entering the Pilot's Compartment.

a. Special Check for Night-flying.

- (1) Turn ignition switch (figure 10) to "BAT."
- (2) Turn cockpit fluorescent lamp (figure 10) and the two cockpit spotlights (figure 10) "ON."
- (3) Test operate fuel gage lights. (See figure 10.)
- (4) Test operate running lights. (See figure 10.)
- (5) Test operate landing lights. (See figure 10.)
- (6) Test operate the compass light brilliancy. (See figure 10.)
- (7) Test operate gun sight lights. (See figure 10.)

b. Check for All Flights.

- (1) Ignition switch (figure 10) "OFF."
- (2) Gun selector switches (figure 10) "OFF."
- (3) Landing gear control handle (figure 8) in neutral.

(4) Flap control handle (figure 8) in neutral.

(5) Parking brake (figure 10) on.

(6) See that controls are FREE.

(7) Turn ignition switch to "BAT."

CAUTION: When turning to the "BAT" position for preflight check be absolutely sure that the switch is not placed in either magneto position ("L" or "R") as the respective engine magnetos will then be "hot" with possible danger to the ground crew.

(8) Fuel selector (figure 8) on "RES." Do not turn selector valve to "BELLY" if the belly tank is not installed.

(9) Generator line switch (figure 10) "ON."

(10) Propeller circuit breaker switch (figure 10) "ON."

(11) Propeller selector switch (figure 10) in "AUTO."

(12) Throttle (figure 8) wide open.

(13) Mixture control on "IDLE CUT-OFF."

(14) Carburetor air heater control (figure 10) in full "COLD" position.

(15) Radiator shutter control (figure 9) as required.

3. Starting Engine.

a. Cold Engine. - With ignition switch (figure 10) "OFF," pull propeller through about three revolutions.

b. Turn ignition switch to "BAT."

c. Prime the engine two to four strokes.

d. ENERGIZE starter.

e. With mixture control (figure 8) in "IDLE CUT-OFF" position and the throttle wide open, operate the electric fuel pump switch (figure 10) to obtain 16 pounds per square inch.

f. Turn ignition switch to "BOTH," and engage the starter.

g. When engine begins to fire, immediately retard throttle and set mixture control to "AUTO-RICH."

CAUTION: If engine does not fire, return mixture control lever to "IDLE CUT-OFF" immediately.

h. Set throttle to maintain an engine speed between 800 and 1000 rpm until the oil pressure begins to come up.

WARNING Do not operate the electrical booster pump with the mixture control out of "IDLE CUT-OFF," when the engine is NOT FIRING. Prime to keep the engine from stalling. Pumping the throttle does NOT prime the engine.

4. Engine Warm-up.

a. Idle the engine between 500 and 800 rpm for 30 seconds after normal idling oil pressure (15 pounds per square inch) is indicated on the gage, and then continue the warm-up between 800 and 1000 rpm.

b. Set radiator shutters as desired.

c. Set carburetor heat control (figure 10) "COLD."

CAUTION: Do not attempt take-off with the carburetor heat control "ON."

5. Emergency Take-off.

If the engine was properly diluted when previously stopped, no trouble should be experienced in maintaining oil pressure within the limits set forth in the SPECIFIC ENGINE FLIGHT CHART in section III.

However, the engine may be flown as soon as it will "take" the throttle, the oil dilution system being operated sufficiently to overcome oil pressure above or below the limits. There is very little danger of over-dilution, so operate the system as the oil pressure gage (figure 10) indicates. Refer to paragraph 8. of this section for routine take-off procedure.

6. Engine and Accessories Ground Test.

a. After warm-up has been completed, advance throttle to obtain 2300 rpm.

b. Test ignition on each magneto.

WARNING This test should never exceed 15 seconds on either magneto. Drop should not exceed 80 rpm on either magneto.

c. Set propeller governor control (figure 8) at 2800 rpm and then set propeller selector switch (figure 10) to "AUTO."

d. Check fuel and oil pressures. Refer to Specific Engine Flight Chart.

e. Check oil and coolant temperatures. Refer to Specific Engine Flight Chart.

7. Taxying Instructions.

The view ahead is poor when taxying; it is, therefore, necessary to keep swinging the airplane from side to side for visibility directly ahead.

CAUTION: Avoid taxying through mud holes and tall grass as the propeller can easily be damaged by small stones, mud clots, or hidden pieces of foreign material. **DO NOT TAXY WITH FLAPS EXTENDED.**

8. Take-off.

a. Preflight Check.

(1) Set rudder trim tab control (figure 8) to neutral.

(2) Set elevator trim tab control (figure 8) to neutral.

(3) Set left aileron trim tab flush with the trailing edge of the aileron by operating switch. (See figure 10.)

(4) Mixture control (figure 8) "AUTO-RICH."

(5) Propeller pitch at 2800 rpm.

(6) Fuel selector valve (figure 8) to "RES." and check fuel pressure. (See figure 10.)

(7) Set flaps as required, but never over one-half way down.

CAUTION: When using flap control handle be sure that the landing gear control is not moved by mistake.

(8) Radiator shutter control (figure 9) wide "OPEN."

(9) See that controls are free.

(10) Refer to section III for all flight operating data.

b. Take-off Procedure.

(1) Raise landing gear and tail wheel as soon as practicable after leaving the ground.

(2) In flight the flaps will go up automatically as soon as the flap control (figure 8) is set in its "UP" position.

CAUTION: Anticipate the sudden resultant loss of lift caused by the raising of the flaps.

9. Engine Failure During Take-off.

a. Nose down immediately.

b. Belly tank (if installed). Pull release lever immediately.

c. Mixture control to "IDLE CUT-OFF."

d. Ignition switch "OFF."

e. Put nose of airplane well down and maintain a gliding speed of approximately 110 mph STRAIGHT AHEAD. DO NOT TRY TO TURN BACK INTO THE FIELD.

CAUTION: LAND AIRPLANE ON ITS BELLY; DO NOT attempt to lower the landing gear.

10. Climb.

If flaps are used for take-off, do not raise them below 500 feet altitude.

11. Flight Operation.

Use the FLIGHT OPERATION INSTRUCTION CHARTS in section III during flight.

12. General Flying Characteristics.

a. Stability. - With normal and full military loads, the airplane is stable.

b. Trim.

Landing gear DOWN	- Nose heavy until retrimmed
Flaps DOWN	- No appreciable change
During dive	- Strong yaw to right
During climb	- Strong yaw to left

c. Order of Fuel Tank Use.

Belly tank (if installed)
Fuselage tank
Main tank
Reserve tank

d. Belly Tank.

(1) If the airplane is equipped with a belly tank, the fuel selector valve (figure 8) should be set at "BELLY" as soon as practicable after take-off.

(2) If the belly tank is dropped during flight, a slight tail heaviness will be observed.

13. Engine Failure During Flight.

a. Drop nose of ship immediately.

b. Ignition switch "OFF."

c. If airplane is equipped with belly tank, pull release lever immediately.

d. Fuel selector valve "OFF."

e. Lower flaps manually with the auxiliary hand pump.

f. If a suitable landing field is available, the landing gear may be lowered. If not, keep landing gear UP and land airplane on its belly.

14. Stalls.

a. Stalling speeds. (Power on.)

Flaps and landing gear DOWN	- 75 mph IAS
Flaps and landing gear UP	- 85 mph IAS

b. Stalls develop very rapidly with a consequent rapid dropping of the nose and a rapid "Whipping" or rolling movement (usually to the left). The airplane has no tendency to go into a spin from a stall.

15. Spins.

Intentional spinning is prohibited; however, if a spin develops, throttle back and apply opposite rudder and at normal load and cg positions, will be effective within two turns. The spin itself is extremely violent.

16. Acrobatics.

Cage gyro horizon indicator before doing acrobatics. All normal acrobatics may be done with the exception of those listed in paragraph 22. of this section.

WARNING Care must be taken to see that ample height is left for recovery from any maneuver, as acceleration during the dive is rapid, and at high speeds the initial pull-out is inclined to be heavy. The elevator trim tab is very sensitive and should not be employed to assist in a pull-out unless absolutely necessary.

17. Diving.

a. Speed Limitation. - Do not exceed a diving speed of 480 mph IAS or 3120 rpm.

b. Stability. - Elevator and rudder loads are heavy at high diving speeds. Strong yaw to the right and right wing heaviness require use of trim tabs to counteract turning and rolling forces.

CAUTION: Pull out should start at 8000 feet for dives at maximum diving speeds.

c. Power Off Dives. - To decrease the possibility of the engine malfunctioning and missing considerably, upon opening the throttle after pull-out from POWER OFF DIVES, the following precaution will be rigidly observed:

"DO NOT CLOSE THE THROTTLE TO ALLOW A MANIFOLD PRESSURE OF LESS THAN 20 INCHES HG DURING DIVE."

18. Emergency Exit.

a. In Flight. - Pull release handle at top forward frame of the cockpit and the entire canopy will open.

b. Turn-over on Ground. - Remove parachute harness, pull the emergency release handle and push open the "kick-out" panel on the left side of the canopy. This panel may be opened from the outside by operating the handle indicated on the lower rear left cabin frame.

19. Approach, Landing and Cross-wind Landing.

a. Approach.

(1) Gun selector switches (figure 10) "OFF."

(2) Mixture control (figure 8) to "AUTO-RICH."

(3) Propeller control (figure 8) to 2230 rpm and slowly close throttle to about 18 inches Hg manifold pressure.

(4) Turn fuel selector valve (figure 8) to a full main tank.

(5) Close radiator shutter as necessary.

(6) Lower the landing gear when the IAS is below 175 mph.

(7) Flaps must not be lowered with air speed above 140 mph IAS.

b. Emergency Operation of Landing Gear. - If the hydraulic switch button on top of the control stick grip and the auxiliary hand pump fail to put the gear down, pump it down with the emergency hydraulic pump. (See figure 9.)

c. Emergency Operation of Flaps. - If the hydraulic switch button on the control stick grip fails to extend the flaps, pump them down with the auxiliary hydraulic hand pump. (See figure 9.)

d. Cross-wind Landing. - Avoid cross-wind landings whenever practicable.

e. Landing. - At conclusion of landing run:

(1) Close throttle.

(2) Open radiator shutters.

(3) Raise the wing flaps.

f. Emergency Take-off if Landing Is Not Completed.

(1) Open throttle and after propeller rpm has stabilized, increase rpm to 2800.

(2) Do not retract flaps until above a 500-foot altitude.

20. Stopping of Engine.

a. Apply toe brakes and set parking brake lever. (See figure 10.)

b. Hold flight control stick back and run engine up to about 18 inches Hg for 30 seconds.

c. When cold-weather starting is anticipated, dilute the oil system for about 4 minutes at 800 rpm before stopping the engine.

d. Move mixture control to "IDLE CUT-OFF," holding oil dilution switch (figure 10) "ON" until engine stops.

e. When propeller stops rotating, turn ignition switch "OFF."

21. Before Leaving the Pilot's Compartment.

a. Fuel selector valve (figure 8) "OFF."

b. All cockpit light switches, pitot heater switch, fuel gage light switches, etc., "OFF."

c. Ignition switch "OFF."

d. Cage gyro horizon indicator.

e. If oxygen has been used during flight, close valve to prevent leakage.

f. Lock flight controls.

g. Make out Form 1.

22. Maneuvers Prohibited.

Outside loop

Inverted flight

Inverted spin

Snap roll at speed in excess of 140 mph IAS

Slow roll at speed in excess of 285 mph IAS

Spin of more than three turns

Spin with baggage, auxiliary fuel, or any other overload

Aerobatics are prohibited when belly tank is installed.

SECTION III

FLIGHT OPERATION DATA

1. Determining Gross Weight.

Refer to the "WEIGHT AND BALANCE CHART" in this section and check the listed basic and alternate tabulated items against those loaded in the airplane. If the airplane is loaded in accordance with the "Basic Load Items" whose weights are entered in the "Pounds" column, and the "Alternate Items" whose weights are entered under four loading conditions in the "Alternate Loading (Pounds)" column, the gross weight will be found listed at the bottom of the chart. If any items tabulated in the "Pounds" column are omitted in the loading of the airplane, deduct the weight of the missing items from the "Gross Weight," and the resulting figure will be the correct gross weight as the airplane is actually loaded.

2. Flight Planning.

a. General.

(1) A series of charts on the following pages is provided to aid in selecting the proper power and altitude to be used for obtaining optimum range of the airplane. A chart is provided for each airplane configuration with its probable range of gross weight.

(2) If the flight plan calls for a continuous flight where the desired cruising power and air speed are reasonably constant after take-off and climb and the external load items are the same throughout the flight, the fuel required and flight time may be computed as a "single section flight." If this is not the case, the flight should be broken up into sections, and each leg of the flight planned separately since dropping of external bombs or tanks causes considerable changes in range and air speed for given power. (Within the limits of the airplane, the fuel required and flying time for a given mission depend largely upon the speed desired. With all other factors remaining equal in an airplane, speed is obtained at a sacrifice of range, and range is obtained at a sacrifice of speed.)

b. Use of Charts.

(1) Although instructions for their use are shown on the "FLIGHT OPERATION INSTRUCTION CHARTS," the following expanded information on proper use of the charts may be helpful.

(2) Select the "FLIGHT OPERATION INSTRUCTION CHART" for the model airplane, gross weight

and external loading to be used at take-off. The amount of gasoline available for flight planning purposes depends upon the reserve required and the amount required for starting and warm-up. The fuel required for warm-up is set forth on the chart. Reserve should be based on the type of mission, terrain over which the flight is to be made, and weather conditions. The fuel required for climb and time to climb to various altitudes is shown on the "TAKE-OFF, CLIMB, AND LANDING CHART." Fuel remaining after subtracting reserve, warm-up, and climb fuel from total amount available is the amount to be used for flight planning.

(3) Select a figure in the fuel column in the upper section of the chart equal to, or the next entry less than, the amount of fuel available for flight planning. Move horizontally to the right or left and select a figure equal to, or the next entry greater than, the distance (with no wind) to be flown. Operating values contained in the lower section of the column number in which this figure appears, represent the higher cruising speeds possible at the range desired. It will be noted that the ranges listed in column I under "Maximum Continuous Power" are correct only at the altitude shown by the note on the chart for this column. The ranges shown in column II and other columns to the right of column II can be obtained at any of the altitudes listed in the "Density Altitude" column. All of the power settings listed in a column will give approximately the same number of miles per gallon if each is used at the altitude shown on the same horizontal line with it. Note that the time required for the flight may be shortened by selection of the higher altitudes. In long range cruising it is important that altitude air speed and rpm be held constant. The manifold pressure should be changed as required to hold the above values reasonably constant.

(4) In order to obtain the flight duration, pilot's indicated air speed must be converted to true air speed and this true speed divided into the air miles to be flown. True air speed may be obtained first by correcting pilot's indicated air speed for position error to obtain an approximate calibrated indicated air speed; then apply the pertinent altitude correction factor to this calibrated indicated air speed. (The air speed indicator on the P-40 series reads about 2 miles per hour slow at 150 miles per hour and about 10 miles per hour slow at 300 miles per hour.) The following table shows the approximate true air speed corresponding to pilot's indicated air speed on the P-40 series airplanes.

PILOT'S
I. A. S.

	APPROXIMATE TIME AIR SPEED			
	5,000	10,000	15,000	20,000
150	165	180	190	210
200	220	240	260	280
250	270	300	320	350
300	330	360	390	415
350	390	420	450	480

(5) The flight plan may be readily changed at any time en route, and the chart will show the balance of range available at various cruising powers by following the INSTRUCTIONS FOR USING CHART printed on each chart.

IMPORTANT: The above instructions and following charts do not take into account the effect of wind. Adjustments to range values and flight duration to allow for wind may be made by any method familiar to the pilot such as by the use of a flight calculator or a navigator's triangle of velocities.

CAUTION: Ranges listed in column I under "Maximum Continuous Power" are correct only at the altitude given in footnote 1, and the engine and airplane operating data listed under OPERATING DATA will give constant miles per gallon if operation is consistent with values set opposite the listed altitudes.

(6) The flight plan may be readily changed at any time en route, and the chart will show the balance of range at various cruising powers by following the "INSTRUCTIONS FOR USING CHART" printed on each page.

If the original flight plan calls for a mission requiring changes in power, speed, gross load, or external load, in accordance with "GR. WT." or "EXTERNAL ITEMS" increments shown in the series of "FLIGHT OPERATION INSTRUCTION CHARTS" provided, the total flight should be broken down into a series of individual shortflights, each computed as outlined in paragraph 2.a. in its entirety, and then added together to make up the total flight and its requirements.

ENGINE MODELS

NEW LANE MODELS

TAKE-OFF, CLIMB & LANDING CHART

P-40D.E

V-1710-39(F-3R)

FORM ASC-510
Dec. 18, 1942
SPEC. AN-18

GROSS WEIGHT (IN LBS.)	HEAD WIND		HARD SURFACE RUNWAY						SOD-TURF RUNWAY						SOFT SURFACE RUNWAY													
			AT SEA LEVEL			AT 3,000 FT.			AT 6,000 FT.			AT SEA LEVEL			AT 3,000 FT.			AT 6,000 FT.			AT SEA LEVEL			AT 3,000 FT.			AT 6,000 FT.	
	MPH	KNOTS	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.	GROUND RUN	TO CLEAR 50' OH.
8700	0	0	1600	2700	1250	2300	2450	3450	1650	2750	2000	3350	2500	3200	1750	2350	2300	3500	1750	2350	2300	3500	2750	3350	1900	2500	1800	3250
	20	17	1000	1900	1250	2350	1600	3000	1050	1350	1300	2400	1650	3050	1100	2000	1400	2500	1100	2000	1400	2500	1800	2600	1100	1900	1050	3150
	40	35	550	1200	700	1550	350	2000	550	1200	750	1600	950	2000	600	1250	800	1650	600	1250	800	1650	1050	2100	600	1150	950	2100
8100	0	0	1300	2200	1600	2800	2000	3300	1350	2250	1650	2050	2050	3350	1450	2350	1750	2350	1450	2350	1750	2350	2200	3500	1900	2500	1800	3250
	20	17	700	1550	1000	1850	1300	2400	950	1500	1050	1300	1300	2400	900	1650	1100	1950	900	1650	1100	1950	1450	2550	1100	1950	1050	3150
	40	35	400	950	550	1150	750	1550	450	1000	550	1150	750	1550	450	1000	600	1200	450	1000	600	1200	800	1600	600	1100	900	2100
7500	0	0	1050	1800	1300	2150	1600	2850	1100	1850	1350	2200	1650	2700	1150	1900	1400	2250	1150	1900	1400	2250	1750	2800	1100	1900	1050	3150
	20	17	650	1200	800	1500	1000	1850	650	1200	800	1500	1050	1300	700	1250	900	1600	700	1250	900	1600	1100	1950	1100	1950	1050	3150
	40	35	300	750	400	950	550	1200	300	750	450	1000	550	1200	350	800	450	1000	350	800	450	1000	600	1250	600	1100	900	2100

NOTE: INCREASE DISTANCE

% FOR EACH 10°C ABOVE 0°C

% FOR EACH 20' F ABOVE 32' F

ENGINE LIMITS FOR TAKE-OFF 3000

RPM & 45.5

IN. HG

% FOR EACH 20°F ABOVE 32°F)

CLIMB DATA

[illegible]

NOTE: INCREASED ELAPSED CLIMBING TIME	% FOR EACH 10°C ABOVE 0°C FREE AIR TEMPERATURE	% FOR EACH 20°F ABOVE 32°F	FUEL INCLUDES WARM-UP AND TAKE-OFF ALLOWANCE

LANDING DISTANCE (INFEET)

GROSS WEIGHT IN LBS.	BEST I. A. S. APPROACH		HARD DRY SURFACE						FIRM DRY SOD						WET OR SLIPPERY					
			AT 3,000 FT.		AT 6,000 FT.		AT SEA LEVEL		AT 3,000 FT.		AT 6,000 FT.		AT SEA LEVEL		AT 3,000 FT.		AT 6,000 FT.			
			TO CLEAR 50' OBL.	GROUND ROLL	TO CLEAR 50' OBL.	GROUND ROLL	TO CLEAR 50' OBL.	GROUND ROLL	TO CLEAR 50' OBL.	GROUND ROLL	TO CLEAR 50' OBL.	GROUND ROLL	TO CLEAR 50' OBL.	GROUND ROLL	TO CLEAR 50' OBL.	GROUND ROLL	TO CLEAR 50' OBL.	GROUND ROLL		
8400	90	78	1750	1100	1850	1200	2000	1300	1200	1950	1300	2100	1400	3100	2450	3350	2700	3650	2950	
7500	84	73	1550	950	1700	1050	1800	1150	1050	1800	1150	1900	1250	2800	2200	3000	2350	3250	2600	

NOTE: FOR GROUND TEMPERATURES ABOVE 35°C (95°F) INCREASE APPROACH I.A.S. 10% AND ALLOW 20% INCREASE IN GROUND ROLL.

NOTE: FOR GROUND TEMPERATURES ABOVE 35°C (95°F) INCREASE APPROACH I.A.S. 10% AND ALLOW 20% INCREASE IN GROUND ROLL.

* REMARKS For five minutes only - then use 2600 RPM & 38.5 IN. HG

I.A.S.: Indicated Air Speed
M.P.H.: Miles Per Hour
S.L.: Sea Level
U.S.: U. S. Gallons
IMP.: Imperial Gallons
NOTE: All Distances are Average
AND FIGURES HAVE NOT BEEN

ENGINE MODELS

TAKE-OFF, CLIMB & LANDING CHART

V-1710-39 (F-3R)

AIRPLANE MODELS

P-40,E

ONE 52 OR 75 GAL. BELLY
TANK OR ONE 500LB. BOMB

TAKE-OFF DISTANCE (IN FEET)

GROSS WEIGHT (IN LBS.)	HEAD WIND (MPH)	HARD SURFACE RUNWAY				SOFT SURFACE RUNWAY			
		AT 3,000 FT.		AT 6,000 FT.		AT 3,000 FT.		AT 6,000 FT.	
		GROUND RUN	TO CLEAR 50' OBL.	GROUND RUN	TO CLEAR 50' OBL.	GROUND RUN	TO CLEAR 50' OBL.	GROUND RUN	TO CLEAR 50' OBL.
9100	0	2100	3600	2800	4400	2350	3850	2200	3700
	20	1350	2500	1700	3150	1500	2650	1300	2450
	40	750	1650	950	2100	800	1700	600	1150
8400	0	1700	2850	2050	3450	1850	3050	1650	2650
	20	1050	2000	1300	2400	1150	2100	950	1850
	40	550	1250	700	1550	600	1300	400	1050
	0								
	20								
	40								

NOTE: INCREASE DISTANCE % FOR EACH 10°C ABOVE 0°C (% FOR EACH 20°F ABOVE 32°F)

ENGINE LIMITS FOR TAKE-OFF 3000 RPM & 45.5 IN. HG

CLIMB DATA

GROSS WEIGHT (IN LBS.)	TYPE OF CLIMB	COMBAT MISSIONS USE 3000				CLIMB DATA				FERRY MISSIONS USE 2300			
		S.L. TO 3,000 FT. ALT.		10,000 FT. ALT.		15,000 FT. ALT.		20,000 FT. ALT.		25,000 FT. ALT.		BPM & 28	
		BEST I.A.S. (MPH)	TIME FROM S.L. (MIN)	BEST I.A.S. (MPH)	TIME FROM S.L. (MIN)	BEST I.A.S. (MPH)	TIME FROM S.L. (MIN)	BEST I.A.S. (MPH)	TIME FROM S.L. (MIN)	BEST I.A.S. (MPH)	TIME FROM S.L. (MIN)	BPM & 28	IN. HG
9100	COMBAT	140	122	1650	3.0	145	125	140	122	130	114	130	114
	FERRY	130	114	600	5.2	135	117	130	114	130	114	130	114
	PERFECT	140	122	1900	2.6	145	125	140	122	130	114	130	114
8400	COMBAT	130	114	700	4.2	135	117	130	114	130	114	130	114
	FERRY	130	114	700	4.2	135	117	130	114	130	114	130	114
	PERFECT	130	114	700	4.2	135	117	130	114	130	114	130	114

NOTE: INCREASED ELAPSED CLIMBING TIME % FOR EACH 10°C ABOVE 0°C FREE AIR TEMPERATURE (% FOR EACH 20°F ABOVE 32°F) FUEL INCLUDES WARM-UP AND TAKE-OFF ALLOWANCE

LANDING DISTANCE (IN FEET)

GROSS WEIGHT (IN LBS.)	BEST I.A.S. APPROACH (MPH)	HARD DRY SURFACE				FIRM DRY SOD				WET OR SLIPPERY			
		AT 3,000 FT.		AT 6,000 FT.		AT 3,000 FT.		AT 6,000 FT.		AT 3,000 FT.		AT 6,000 FT.	
		GROUND RUN	TO CLEAR 50' OBL.	GROUND RUN	TO CLEAR 50' OBL.	GROUND RUN	TO CLEAR 50' OBL.	GROUND RUN	TO CLEAR 50' OBL.	GROUND RUN	TO CLEAR 50' OBL.	GROUND RUN	TO CLEAR 50' OBL.
8500	95	1600	1050	1750	1150	1850	1250	1700	1150	1950	1350	2500	1750
	88	1450	950	1550	1000	1700	1100	1550	1050	1800	1200	2250	1600
	80	1300	850	1400	900	1550	1050	1400	950	1650	1100	2000	1450

NOTE: FOR GROUND TEMPERATURES ABOVE 35°C (95°F) INCREASE APPROACH I.A.S. 10% AND ALLOW 20% INCREASE IN GROUND ROLL.

REMARKS * For five minutes only - then use 7500 RPM & 38.5 IN. HG

I.A.S.: Indicated Air Speed
M.P.H.: Miles Per Hour
S.L.: Sea Level
U.S.: U.S. Standard
IMPH: Imperial Gallons
NOTE: All Distances are Average
RED FIGURES HAVE NOT BEEN FLIGHT CHECKED

EXTERNAL LOAD ITEMS

POUNDS

ONE... 52... OR... 75... GAL... BELLY... TANK... OR...

CONDITION	R.P.M.	IN. (H.P.)	BLOWER POSITION	MIXTURE POSITION	DURATION IN MIN.	U.S. G.P.H.	I.M.P.
TAKE-OFF	3000	45.5	-	A R	5	140	117
MILITARY POWER	3000	44.6	-	A R	5	132	110

RESERVE FUEL ALLOWANCE

WHO WIND!

I (MAX. CONT. POWER)				II				III				IV				V (MAX. RANGE)			
RANGE IN AIR MILES				RANGE IN AIR MILES				RANGE IN AIR MILES				RANGE IN AIR MILES				RANGE IN AIR MILES			
STATUTE		NAUTICAL		STATUTE		NAUTICAL		STATUTE		NAUTICAL		STATUTE		NAUTICAL		STATUTE		NAUTICAL	
AT 5 L.	AT 9000	AT 5 L.	AT 9000																
FUEL U. S. GALS. ①				FUEL U. S. GALS. ①				FUEL U. S. GALS. ①				FUEL U. S. GALS. ①				FUEL U. S. GALS. ①			
200				200				200				200				200			
355				355				355				355				355			
420				420				420				420				420			
395				395				395				395				395			
370				370				370				370				370			
345				345				345				345				345			
320				320				320				320				320			
280				280				280				280				280			
260				260				260				260				260			
235				235				235				235				235			
215				215				215				215				215			
195				195				195				195				195			
170				170				170				170				170			
150				150				150				150				150			
130				130				130				130				130			
110				110				110				110				110			
90				90				90				90				90			
70				70				70				70				70			
50				50				50				50				50			
30				30				30				30				30			
10				10				10				10				10			
0				0				0				0				0			
R.P.M.				R.P.M.				R.P.M.				R.P.M.				R.P.M.			
I.A.S. M.P.H.				I.A.S. M.P.H.				I.A.S. M.P.H.				I.A.S. M.P.H.				I.A.S. M.P.H.			
I.A.S. M.P.H.				I.A.S. M.P.H.				I.A.S. M.P.H.				I.A.S. M.P.H.				I.A.S. M.P.H.			
M.P. IN. HG.				M.P. IN. HG.				M.P. IN. HG.				M.P. IN. HG.				M.P. IN. HG.			
U.S. G. P. H.				U.S. G. P. H.				U.S. G. P. H.				U.S. G. P. H.				U.S. G. P. H.			
ALT. IN FEET				ALT. IN FEET				ALT. IN FEET				ALT. IN FEET				ALT. IN FEET			
30000				30000				30000				30000				30000			
25000				25000				25000				25000				25000			
20000				20000				20000				20000				20000			
15000				15000				15000				15000				15000			
12000				12000				12000				12000				12000			
9000				9000				9000				9000				9000			
6000				6000				6000				6000				6000			
3000				3000				3000				3000				3000			
S. L.				S. L.				S. L.				S. L.				S. L.			

I.A.S.: Indicated Air Speed
M.P.: Manifold Pressure (In. Hg)
U.S.G.P.M.: U. S. Gallons Per Hour
IMP.G.P.M.: Imperial Gallons Per Hour
F.T.: Full Throttle
S.L.: See Level

ENGINE TO "SPECIFIC ENGINE FLIGHT CHART" FOR ADDITIONAL ENGINE OPERATION DATA.

RED FIGURES ARE PRELIMINARY: SUBJECT TO REVISION AFTER FLIGHT CHECK

MODEL (S)
P-40 & F

FLIGHT OPERATION INSTRUCTION CHART
SHEET 2 OF 2 SHEETS

GR. WT. 8300 **POUNDS**

ONE 52.07 75 gal. BELLY TANK or
ONE 500 lb Bomb

EXTERNAL LOAD ITEMS

except in emergency. (B) Columns (II, III, IV & V) toward the right progressively give increase in range at sacrifice in speed. (C) Manifold Pressure (M.P.). Gallons Per Hour (G.P.H.) are approximate maximum values for reference. (D) For quick reference, take-off and military power data are listed in the upper left corner of chart.

INSTRUCTIONS FOR USING CHART: Select figure in fuel column equal to or less than total amount of fuel in airplane. Move horizontally to the right or left and select a figure equal to or greater than the air miles to be flown. Vertically below and opposite desired cruising altitude read optimum cruising conditions. **NOTES:** (A) Avoid continuous cruising in Column I.

ALTERNATE CRUISING CONDITIONS

I (MAX. CONT. POWER)				II				III				IV				V (MAX. RANGE)			
FUEL U.S. GALS.				FUEL U.S. GALS.				FUEL U.S. GALS.				FUEL U.S. GALS.				FUEL U.S. GALS.			
RANGE IN AIR MILES				RANGE IN AIR MILES				RANGE IN AIR MILES				RANGE IN AIR MILES				RANGE IN AIR MILES			
STATUTE				STATUTE				STATUTE				STATUTE				STATUTE			
AT S.L.	AT 9,000	AT S.L.	AT 9,000	AT S.L.	AT 9,000	AT S.L.	AT 9,000	AT S.L.	AT 9,000	AT S.L.	AT 9,000	AT S.L.	AT 9,000	AT S.L.	AT 9,000	AT S.L.	AT 9,000		
350	325	300	275	250	225	200	175	150	125	100	75	50	25	100	75	50	25		
300	275	250	225	200	175	150	125	100	75	50	25	100	75	50	25	100	75		
250	225	200	175	150	125	100	75	50	25	100	75	50	25	100	75	50	25		
200	175	150	125	100	75	50	25	100	75	50	25	100	75	50	25	100	75		
150	125	100	75	50	25	100	75	50	25	100	75	50	25	100	75	50	25		
100	75	50	25	100	75	50	25	100	75	50	25	100	75	50	25	100	75		
75	50	25	100	75	50	25	100	75	50	25	100	75	50	25	100	75	50		
50	25	100	75	50	25	100	75	50	25	100	75	50	25	100	75	50	25		
25	100	75	50	25	100	75	50	25	100	75	50	25	100	75	50	25	100		

OPERATING DATA

I				II				III				IV				V			
R.P.M.				R.P.M.				R.P.M.				R.P.M.				R.P.M.			
I.A.S.				I.A.S.				I.A.S.				I.A.S.				I.A.S.			
M.P.H.				M.P.H.				M.P.H.				M.P.H.				M.P.H.			
M.P.				M.P.				M.P.				M.P.				M.P.			
U.S. G.P.H.				U.S. G.P.H.				U.S. G.P.H.				U.S. G.P.H.				U.S. G.P.H.			
U.S. G.P.H.				U.S. G.P.H.				U.S. G.P.H.				U.S. G.P.H.				U.S. G.P.H.			
2600	222	193	164	2600	222	193	164	2600	222	193	164	2600	222	193	164	2600	222	193	
2600	236	205	176	2600	236	205	176	2600	236	205	176	2600	236	205	176	2600	236	205	
2600	243	211	182	2600	243	211	182	2600	243	211	182	2600	243	211	182	2600	243	211	
2600	245	213	184	2600	245	213	184	2600	245	213	184	2600	245	213	184	2600	245	213	
2600	248	215	186	2600	248	215	186	2600	248	215	186	2600	248	215	186	2600	248	215	
2600	249	216	187	2600	249	216	187	2600	249	216	187	2600	249	216	187	2600	249	216	

INDICATED ALTITUDE CORRECTED FOR FREE AIR TEMPERATURE

ALLOW 26 U.S. GALS. 22 IMP. GALS. FOR WARM UP.

TAKE-OFF AND CLIMB TO 5000 FEET ALTITUDE

RETURN FUEL FLOWS TO TANK.

USE FUEL FROM TANKS IN THE FOLLOWING ORDER

FROM TO "SPECIFIC ENGINE FLIGHT CHART" FOR ADDITIONAL ENGINE OPERATION DATA.

LEGEND

1 INDICATED ALTITUDE CORRECTED FOR FREE AIR TEMPERATURE

2 ALLOW 26 U.S. GALS. 22 IMP. GALS. FOR WARM UP.

3 TAKE-OFF AND CLIMB TO 5000 FEET ALTITUDE

4 RETURN FUEL FLOWS TO TANK.

5 USE FUEL FROM TANKS IN THE FOLLOWING ORDER

6 FROM TO "SPECIFIC ENGINE FLIGHT CHART" FOR ADDITIONAL ENGINE OPERATION DATA.

SECTION IV
OPERATION OF OXYGEN EQUIPMENT

1. Operation.

a. Oxygen will be used when operating above 12,000 feet pressure altitude.

b. The pilot's oxygen mask nose may have a rubber bayonet or metal connector. Be absolutely sure that the mask connector will fit the regulator output connection before starting the airplane's engine.

c. The airplane low pressure oxygen bottle is located in the aft part of the fuselage and is accessible through the fuselage access door. (See figure 2.) It is satisfactory for take-off if the gage attached to the neck of the bottle shows a minimum of 300 pounds. The bottle is equipped with a shut-off valve which should be opened before and closed after each flight to prevent possible leakage.

d. Oxygen flow to the pilot is controlled by a regulator located in the floor of the cockpit to the right


of the pilot. A small knob for adjustment and a gage calibrated in thousands of feet for flow indication are provided. When oxygen is being taken by the pilot, the knob should be adjusted so that the gage registers equal to the pressure altitude at which the airplane is flying. Some pilots require more oxygen than others and the flow should be increased if the pilot feels any extremity of his body (lobes of the ears, feet or fingers) lacking in sensitiveness or has any tingling sensation.

2. Oxygen Duration.

a. Type F-1 cylinder weighing 7 pounds will supply oxygen for one man as follows:

2-1/4 hours at 25,000 feet with a type A-9A regulator

2-3/4 hours at 25,000 feet with a type A-9 regulator



SECTION V
OPERATION OF COMMUNICATIONS EQUIPMENT

1. Radio Set SCR-283 (P-40D Airplane).

a. Receiver Operation.

(1) The radio receiver is located in the aft part of the fuselage and is accessible through the fuselage access door. (See figure 2.) All tuning dials and switches are located in the pilot's cockpit along the upper right longeron. (See figure 9.)

(a) The receiver may be identified by a large 0-100 calibration dial on the front end.

(b) Spare coils for change of receiver frequency tuning range are mounted near the receiver and may be identified the same way as for the receiver.

(2) Turn ignition switch (figure 10) to "BAT."

WARNING If the airplane is on the ground and the engine is not running, be sure that the switch is NOT on "L" or "R."

(3) Turn receiver volume control selector switch (figure 9) to "MANUAL." Plug phones in jack, and turn volume control knob (figure 9) to the right until a faint frying noise is heard in the phones. Automatic volume control may be used by setting the selector switch (figure 9) in "AUTO"; this setting is most suitable for hunting a signal.

CAUTION: For all normal (voice or MCW) reception the radio receiver crystal filter selector switch (figure 9) should be set at "BOTH." To receive the radio range without possibility of voice interference, set the selector switch to "VOICE." It is impossible to receive voice when this selector switch is set on "RANGE."

(4) Reception at Different Frequencies.

(a) To receive the U. S. Airways Radio Range 210-398 kilocycles, set the "HI-LO" selector switch (figure 9) at "LO." Refer to CAUTION under paragraph 1.a.(3) above. Adjust tuning dial knob (figure 9) for desired frequency as calibrated on the scale closest to the center of the tuning dial.

(b) Provisions are made for plugging in different coils to cover almost every range of frequency practicable and available for aircraft use. The frequency range in kilocycles, along with the coil-identifying number, is fixed to the handle of every "plug-in" coil. Before starting the airplane's engine, the pilot should check the coil in his receiver, and if its range in kilocycles does not include the desired frequency, the proper coil should be inserted.

(c) For tuning the receiver to any frequency other than the radio range band regardless of the coil that is in use, always set the "HI-LO" switch (figure 9) to "HI." If the frequency range of the coil in the receiver matches the rear (outer) scale frequency calibration on the tuning dial in the cockpit, the tuning to any frequency within the dial calibration will be by direct reading in kilocycles. If the coil does not match the rear (outer) scale on the tuning dial, the intermediate (middle, 0-100) scale will be used for tuning. In this case, there will be found a metal "Frequency in Kc" calibration chart fixed in every cockpit near the tuning dial. Frequency in kilocycles for different coil numbers is plotted on this card against the 0-100 center tuning dial scale. When tuning to any desired frequency in kilocycles, use the vertical column on the card that is headed by the same coil number that is plugged into the receiver, and set tuning dial scale (center scale) at the number found opposite the frequency desired.

(5) To Receive Code (CW).

(a) Straight continuous wave signals cannot be heard on this receiver, as it is not equipped with a beat frequency oscillator.

(b) Modulated CW signals (similar to the airways course signals) may be heard by this receiver by tuning in the same manner as for voice reception with the radio range filter selector switch (figure 9) set on "BOTH" or "RANGE."

(c) The receiver may be turned off by setting the control knob (figure 9) in the "OFF" position.

CAUTION: If there is no further use of electrical equipment in the airplane, turn the ignition switch (figure 10) "OFF" before leaving the cockpit.

b. Transmitter Operation.

(1) General. - The transmitter is located in the aft part of the fuselage and is accessible through the fuselage access door. (See figure 2.) All controls and switches are located in the pilot's cockpit along the upper right longeron. (See figure 9.)

(2) To Transmit Voice Signals.

(a) If airplane is on the ground and the engine is not running, turn ignition switch (figure 10) to "BAT."

(b) Turn transmitter master knob (figure 9) "ON," and allow the transmitter to warm up at least 1 minute before attempting to transmit.

1. Set transmitter emission control switch (figure 9) to "VOICE."

2. To talk, hold microphone directly in front of and within 1/2 inch of the lips, press the button on the rear side, and speak slowly with clean, sharp distinct words. Release microphone button when transmission is ended.

WARNING If a throat microphone is used, it must be adjusted so that its two circular elements are held snugly against each side of the throat just above the "Adam's apple." SPEAK SLOWLY, DISTINCTLY, AND IN A NORMAL TONE OF VOICE. Shouting will seriously distort the voice signal.

(3) To Transmit Code Signals (CW).

(a) Turn ignition switch (figure 10) to "BAT" if airplane is on ground and engine is not running.

(b) Set transmitter emission control switch (figure 9) to "CW."

(c) Operate the transmitting key (figure 9) on top of the transmitter emission control switch box.

(d) When operating in code with any other airplane using the same model transmitting and receiving equipment, set the switch box selector switch (figure 9) to "TONE" and proceed as outlined above.

(e) The transmitting key may be adjusted for travel by regulating the thumb screw on the bottom of the box directly under the key.

2. Radio Set SCR-274-N (P-40E Airplane).

a. Description. - The command set SCR-274-N is designed for short-range operation, and is used for communicating with nearby aircraft for tactical purposes and with ground stations for navigation and traffic control purposes. Three receivers and two transmitters are installed in the rear of the fuselage and are accessible through the fuselage access door. (See figure 2.) All dials and controls are located on remote control units located to the right of the pilot.

b. Receiving.

(1) The receiver remote control unit is divided into three identical sections, each section controlling the particular receiver to which it is electrically and mechanically connected. Reception of a signal of a specific frequency as indicated on the dial is accomplished by the use of the section of the receiver control box which controls the particular receiver involved.

(2) Plug head-set phone jack plug in jack No. . Turn volume control (figure 9) to the right until a faint "frying" noise is heard in the phones.

(3) Set crystal filter selector switch (figure 9) to "BOTH" for all normal (voice or MCW) reception.

(4) Turn switch (figure 9) on. This switch, in addition to having an "OFF" position, has two selective positions marked "CW" and "MCW," each of which is an "ON" position and indicates the type of signal which is to be received.

NOTE: When tuning receiver for a definite frequency, always turn dial a little to each side of the frequency calibration mark to find the point where the signal is the strongest.

(5) The A-B switches should be left in the "A" position at all times, and need not be turned off when the receiver is turned off.

c. Transmitting.

(1) Before transmitting, adjust radio receiver to the same frequency as the station with which you desire to talk, and listen in to be sure that the operator is not talking to some one else. If the station is transmitting, take advantage of the opportunity to more accurately set the receiver on the assigned frequency, and when the other operator is finished, proceed with your transmission.

(2) Place transmitter master switch (figure 9) in "ON" position.

(3) Select type of transmission desired with switch marked "TONE-CW-VOICE." (See figure 9.)

(a) With the switch in the "VOICE" position, voice will be transmitted when the push-to-talk button is pressed.

(b) With the switch in the "CW" position, a continuous wave, or unmodulated signal, will be transmitted. The microphone is inoperative.

(c) With the switch in the "TONE" position, a modulated tone signal is transmitted. The microphone is inoperative.

NOTE: Greatest effective range can be obtained on "CW." Range is most limited when operating on "VOICE." Transmitting in both "CW" and "VOICE" positions is done by a key located on the end of the transmitter control unit.

(d) To reduce battery drain and to increase dynamotor life, the "TONE-CW-VOICE" switch (figure 9) should be left on "VOICE" unless continued use on "CW" or "TONE" is expected.

3. Radio Set SCR-522A (P-40E Airplane).

a. General.

(1) This equipment is an ultra high-frequency (UHF) command set designed for voice communication only. It is used in conjunction with a contactor

(pip squeak) for identification and navigational purposes. A remote control unit is located in the pilot's cockpit to the right of the pilot.

(2) The radio waves from this equipment travel in straight lines, like beams of light, and do not follow the curvature of the earth. Due to this fact, in order to receive signals from a ground station, it is necessary that an airplane be above a certain altitude which is determined by the distance of the airplane from the ground station.

(a) If the airplane is between 35 and 50 miles away from the ground station, it must be above 1000 feet before reception is possible.

(b) If the airplane is between 80 and 100 miles away from the ground station, it must be above 5000 feet before reception is possible.

(c) If the airplane is between 120 and 160 miles away from the station, it must be above 10,000 feet before reception is possible.

NOTE: If the distance of the airplane from the station differs from any of the above examples, the altitude will change proportionately.

(3) Excessive operation of this equipment on the ground must be avoided unless a battery cart is used to prevent running down the airplane's battery.

b. Operation.

(1) Press the proper channel button on the cockpit control box, for the frequency on which you are to transmit and receive to put the set in operation.

NOTE: Transmission and reception take place on the same frequency.

(2) A green warning lamp adjacent to the channel button, pressed, lights up, whenever the set is in operation.

(3) A white pilot light adjacent to the toggle switch should light up indicating that the set is on "receive."

(4) For throttle microphone button transmission, place toggle switch in "REM" position.

NOTE: "REM" (remote) was marked "V.O." on early control boxes.

(5) Press microphone button, press the throttle "push-to-talk" button, and speak in a loud voice with the microphone against your lips. The white pilot lamp goes out immediately indicating that the set is on "transmit."

(6) It is also possible to transmit by moving the control box toggle switch to the "T" position, instead of pressing the throttle "push-to-talk" button. However, it must be returned to either the "R" or "REM" position immediately after transmission is completed.

c. **Dimmer.** - The set is turned off by pushing the "OFF" button. Indicator lamps on the control box are provided with a dimmer mask for night-flying. The mask is operated by movement of a small lever beside the "OFF" push-button.

4. Pip Squeak (Contactor) Operation - RC-96 - (P-40E Airplane).

a. The pip squeak (contactor) can be used with either the SCR-274-N or the SCR-522-A command set.

b. When the contactor clock on the instrument board is turned on, the transmitter is in operation. It sends out a 14-second tone signal once every minute on channel "D" when used with the SCR-522 set and on channel "2" when used with the SCR-274-N set. Transmission of the signal occurs during the period that the hand is moving through the marked quadrant on the face of the clock.

c. Connect contactor clock to radio set by placing switch in the "IN" position.

d. Start clock by placing clock master switch in the "RUN" position.

e. When the clock takes over, the channel selector switch automatically goes to the proper channel and a continuous tone is heard both in the phones and on the ground for 14 seconds. At the end of the 14-second signal period, the selector switch automatically returns to the original channel.

WARNING

It is impossible to transmit or receive voice during the 14-second tone signal period.



SECTION VI

ARMAMENT EQUIPMENT

1. Bombing Equipment.

Six bombs may be carried externally, three below each wing. To release them electrically, place selector switch (figure 10) in the "ON" position and press the trigger switch on the control stick grip. They may be manually released by placing the bomb release handle (figure 8) in the full forward position. If a 300-or 500-pound bomb is carried instead of a belly tank, it can be dropped by pulling belly tank release handle. (See figure 8.)

2. Gunnery Equipment, P-40D Airplane.

a. General. - Two .50-caliber fixed machine guns are mounted in each wing panel, and fire clear of the propeller arc. They are charged by placing the control valves (figure 8) in the "ON" position. Should the electric hydraulic pump fail, pressure may be retained by use of the auxiliary hand pump. (See figure 9.) Structural provisions are made for external attachment of two 20-mm cannon, one on the bottom surface of each wing. A miniature gun camera may be mounted on the gun sight.

b. Operation.

(1) The guns are fired by placing the selector

switch (figure 10) in the "ON" position and pressing the trigger switch on the control stick grip. All guns are either "ON" or "OFF."

(2) To operate the gun camera, place the gun camera safety switch (figure 10) in the "ON" position and press the trigger switch on the control stick grip.

(3) To operate the electric gun sight, open the cover on the sight lens (figure 11), turn ignition switch to "BAT" and adjust rheostat control (figure 10) until the sight lines can be seen by looking through the small reflection glass centrally located just behind the windshield in line with the pilot's eyes.

3. Gunnery Equipment, P-40E Airplane.

a. General. - Three .50-caliber machine guns are mounted in each wing panel, and fire clear of the propeller arc. No provisions are made for the installation of cannon. The installations of the gun camera and gun sight are the same as for the P-40D airplane.

b. Operation. - Operation of the guns, camera, and gun sight is the same as for the P-40D airplane. Refer to paragraph 2.b. above.




Figure 11 - Gun Sight and Gun Camera Installed

APPENDIX

COLD WEATHER OPERATION

1. Engine Oil Dilution System.

a. General.

(1) Oil dilution provides a method of diluting or thinning the engine oil with gasoline at the end of each engine run in order to facilitate starting the engine in cold weather.

(2) The engine oil should be diluted prior to stopping the engine when there is a possibility of the engine oil temperature dropping below approximately 5°C (41°F) during the period the engine is to be inoperative.

b. Operation.

(1) Maintain a speed of 800 rpm. If a higher speed is maintained, the oil temperature will exceed the maximum temperature limit set for the diluting period. Fuel vapor blown from the breather outlets to the exhaust stacks by the propeller blast also creates a great fire hazard.

NOTE: It is impossible to dilute the engine oil unless the engine is running.

(2) Maintain the oil temperature below 50°C (122°F) during the dilution procedure. The ideal temperature is 40°C (104°F). If the oil temperature exceeds 70°C (158°F), the gasoline will evaporate as rapidly as it is introduced into the oil and will leave the oil with its original viscosity. If the oil temperature exceeds 50°C (122°F) when the airplane is landed, the engine must be stopped and the oil allowed to cool to approximately 35°C (95°F) before the engine is started again to accomplish oil dilution.

(3) Hold the oil dilution switch (figure 10) in the "ON" for about 4 minutes with an engine speed of 800 rpm. The engine must be stopped at the end of the dilution period by moving the mixture control (figure 8) to the "IDLE CUT-OFF" position. If a sharp decrease in fuel pressure is not noted during oil dilution, check the electrical oil dilution circuit, the oil dilution valve, and the pressure gage for the source of the trouble.

2. Portable Ground Heater (Type D-1).

a. When operating under freezing conditions and if weather conditions require preheating of the engine, use type D-1 portable heaters.

b. It requires approximately 15 minutes to heat up the engine at -17.8°C (0°F) and approximately 30 minutes at -34.4°C (-30°F). The heater is equipped with three flexible warm air ducts.

c. The heater weighs approximately 210 pounds, is equipped with two rubber wheels and a skid and is easily handled by one man.

CAUTION: Whatever method is used for preheating the engine, extreme care must be taken to prevent accidental ignition of the gas fumes from the engine breathers, caused by vaporization of the gasoline in the oil.

3. Cold Weather Starting of Engine.

When the engine is to be started for warm-up, or is to be repeatedly started and stopped for ground test purposes or "alert," the engine will be primed and the oil dilution system operated in accordance with instructions given in paragraph 1.b. of this section.

WARNING In warming a cold engine in extremely cold weather, start with radiator shutters closed. Do NOT run engine to more than 800 rpm until oil has reached a temperature of 40°C (104°F).

4. Batteries.

Energizers or battery carts are generally used for cold weather starting, as this is more practicable than heating the batteries. Batteries should be maintained at not less than -12.2°C (10°F). Lower voltage at extremely low temperatures causes malfunctioning of all electrical equipment.

NOTE: To safeguard battery, remove it from the airplane and store it in a heated place when the airplane is to be idle overnight.

5. Frost or Ice Removal.

When it is necessary to remove frost or ice from areas of the airplane, melt a small area of the ice-covered surface at a time using hot water, then flush this area with denatured alcohol before the hot water freezes. Pay particular attention to hinges and controls. Alcohol should be used for cleaning frost off windshield and canopy.

6. Mooring.

If, due to extreme cold weather, mooring stakes cannot be driven into the ground, use a pick or other sharp instruments and dig a hole approximately 8 inches deep and 8 inches square. Into this hole place two deeply notched stakes crosswise, and then tie the mooring rope to the stakes. Fill the hole with water which will freeze the stakes and rope fast. If stakes are unavailable, dig the hole, coil the rope in the bottom of it, and then fill with water.

7. Communications Equipment.

The following equipment is adversely affected by extreme cold weather.

Dynamotor. - The increased viscosity of bearing lubricants may prevent the dynamotor from starting, resulting in blown fuses. If this occurs, grease should be removed and oil substituted as a lubricant.

Controls, Hand Switches, Etc. - Stiffness of operation may occur. Oil should be removed in order to prevent drag and binding.

Batteries. - Cracking occurs around the edge of the case. Batteries should be kept charged above 1.290

specific gravity to prevent cracking.

Microphones. - The hand microphone is unsatisfactory for use in cold weather. Moisture collects and freezes in the small holes of the microphone cap. Throat type microphones should be used for all cold weather operations.

Transmitter. - In certain types of transmitters, frequency shifts occur with wide changes in temperature. Consequently the transmitter must be retuned and checked until a relatively stable temperature is reached.

Plugs (Jacks). - Cracking occurs on type PL-54. No remedy can be effected.

APPENDIX

EMERGENCY OPERATING INSTRUCTIONS

1. Emergency Take-off.

If the oil was properly diluted when the engine was previously stopped, no trouble should be experienced in maintaining oil pressure within the limits set forth on the SPECIFIC ENGINE FLIGHT CHART in section III. However, the engine may be flown as soon as it will "take" the throttle, the oil dilution system being operated sufficiently to overcome oil pressure above or below the limits. There is very little danger of overdilution, so operate the system as the oil pressure gage (figure 10) indicates. Refer to paragraph 8. of section II for routine take-off procedure.

2. Engine Failure During Take-off.

a. Nose down immediately.

b. Belly tank (if installed) - Pull release lever immediately.

c. Mixture control - "IDLE CUT-OFF."

d. Ignition switch - "OFF."

e. Put nose of airplane well down and maintain a gliding speed of approximately 110 mph STRAIGHT AHEAD.

CAUTION: LAND AIRPLANE ON ITS BELLY. DO NOT ATTEMPT TO LOWER LANDING GEAR.

3. Engine Failure During Flight.

a. Drop nose of ship immediately.

b. Ignition switch "OFF."

c. If belly tank is installed, pull release lever immediately.

d. Fuel selector valve "OFF."

e. Lower flaps manually with auxiliary hand pump.

f. If a suitable landing field is available, the landing gear may be lowered. IF NOT, KEEP LANDING GEAR UP AND LAND AIRPLANE ON ITS BELLY.

4. Emergency Take-off if Landing is not Completed.

a. Open throttle and after propeller rpm has stabilized, increase rpm to 2800.

b. Do not retract flaps until above 500 feet.

5. Emergency Exit.

a. In Flight.

(1) Canopy. - An emergency canopy release handle is located on the upper forward beam of the canopy in front and above the pilot. To release the canopy pull down on it. This will break the lock wire on the release mechanism and the slip stream will tear off the canopy.

(2) Kick-out Panel. - The kick-out panel on the left side of the canopy may be opened by pulling inward and aft on the release handle.

b. Turnover on Ground. - The kick-out panel may be opened from the inside by pulling inward and aft on the release handle and pushing out on the panel. It may be opened from the outside by pulling outward and forward on the handle.

6. Emergency Operation of Landing Gear.

a. If the electrical system doesn't work, the landing gear can be operated by placing the landing gear control handle (figure 8) in the desired position and then pumping the auxiliary hand pump. (See figure 9.)

b. Should the auxiliary hand pump fail, the landing gear may be operated by means of the emergency hydraulic hand pump. (See figure 9.) The emergency system may be operated by removing the handle from the auxiliary hand pump and placing it on the emergency hand pump. The hand shut-off valves on the floor of the cockpit must be opened before operating the emergency system.

WARNING A "tail high" landing must be made when the emergency hydraulic system is used, as the tail wheel can not be moved by the emergency system.

7. Emergency Operation of Wing Flaps.

If the electric hydraulic pump doesn't work, the flaps may be lowered manually by placing the flap control handle (figure 8) in the "DOWN" position, and pumping the auxiliary hand pump. (See figure 9.) The emergency hydraulic system does not operate the flaps.

8. Emergency Bomb Release.

The bombs are released manually by placing the bomb release handle (figure 8) in the forward position.

9. Belly Tank Release.

The belly tank (or belly bomb, if installed) can be released by pulling up on the belly tank release handle. (See figure 8.)

APPENDIX

GLOSSARY

U.S.

Air field
Battery storage
Beam, landing
Ceiling
Course
Empennage
Filter, air
Glass, bullet proof
Gyro, directional
Horizon, gyro
(to) Land
Lean
Left
(to) Level off
Line handling
Line, Mooring
Mast radio
Nose-heavy
Pressure Manifold
P-40D, -E
Reticule
Right
Roll, snap
Set, command
Speed, indicated air
Stabilizer, horizontal
Stabilizer, vertical
Tab, trim
Tachometer
Tube, radio
Wing

BRITISH

Aerodrome
Accumulator
Approach beam
Cloud height
Track angle
Tail unit
Air cleaner
Armour glass
Gyroscopic turn indicator
Artificial horizon
(to) Alight
Weak
Port
(to) Flatten out
Handling guy
Mooring guy
Rod aerial
Bow-heavy
Boost pressure
Kittyhawk I or IA
Graticule
Starboard
Stick roll
Pilot controller set
Air-speed-indicator reading
Tail plane
Fin
Trimming tab
Engine speed indicator (E.S.I.)
Valve
Main plane